


FIG. 1



**FIGURE 2**




FIGURE 3.

[120 Search All My Quotes](#)
[142 Request New Quote](#)

**Product Configurator**

[136 Preview Quote](#)
[138 Save Quote](#)
[140 Submit Order](#)

User Name: John Doe  
 2/21/2001

Customer Name:  
 Quote Number:

124 Customer

126 Project Details

128 System

130 Engine Generator

132 Distribution Breaker

134 Pricing

1 Customer

2

3

4

5

6

### Customer Lookup

☒ Required for Order.

146 Customer Name  
 148 Customer Number

152 Address Line 1  
 152 Address Line 2  
 154 City  
 156 State  
 158 Zip

136 Preview Quote

138 Save Quote

140 Submit Order

FIGURE 4.

[Search All My Quotes](#)    [Request New Quote](#)

---

## Product Configurator

User Name: John Doe  
 2/21/2001

Customer Name: \_\_\_\_\_  
 Quote Number: XXX-123-1234

[Preview Quote](#)
[Save Quote](#)
[Submit Order](#)

Customer	Project Details	System	Engine Generator	Distribution Breaker	Pricing
1	2	3	4	5	6

### Project Details

Project Name: \_\_\_\_\_

Location: \_\_\_\_\_

Contact Name: \_\_\_\_\_

Contact Email: \_\_\_\_\_

Contact Phone: \_\_\_\_\_

Contact Fax: \_\_\_\_\_

### Shipping Information

Address Line 1: \_\_\_\_\_

Address Line 2: \_\_\_\_\_

City: \_\_\_\_\_

State: \_\_\_\_\_

Zip: \_\_\_\_\_

### Engineering Firm

Firm Name: \_\_\_\_\_

Engineer Name: \_\_\_\_\_

City: \_\_\_\_\_

Country: \_\_\_\_\_

Engineer Email: \_\_\_\_\_

Engineer Phone: \_\_\_\_\_

Engineer Fax: \_\_\_\_\_

### Electrical Contractor

Company Name: \_\_\_\_\_

Contact Name: \_\_\_\_\_

Contractor Email: \_\_\_\_\_

Contractor Phone: \_\_\_\_\_

Contractor Fax: \_\_\_\_\_

[Preview Quote](#)
[Save Quote](#)
[Submit Order](#)

FIGURE 5.

230

[Search All My Quotes](#) 142    [Request New Quote](#) 144

### Product Configurator

User Name: John Doe  
 2/29/2007

Customer Name: Customer Name  
 Quote Number: 123-1234

[Preview Quote](#) 136    [Save Quote](#) 138    [Submit Order](#) 140

[Customer](#) 124    [Project Details](#) 126    [System](#) 128    [Engine Generator](#) 130    [Distribution Breaker](#) 132    [Pricing](#) 134

122

### System

232 System Voltage  
 234 Number of Generators  
 236 Size of Generators  
 238 Enclosure  
 240 UL Listed  
 242 Short Circuit Ratio  
 244 Main Bus Size  
 246 Main Bus Metering

☒ Required for Order

248

[Preview Quote](#) 136    [Save Quote](#) 138    [Submit Order](#) 140

FIGURE 6.

[Search All My Quotes](#) [Request New Quote](#)

**Product Configurator**

[Preview Quote](#)
[Save Quote](#)
[Submit Order](#)

User Name: John Doe  
 272102001

Customer Name: Customer Name  
 Quote Number: 120-1234

[Customer](#)
[Project Details](#)
[System](#)
[Engine Generator](#)
[Distribution Breaker](#)
[Pricing](#)

122

### Engine-Generator

☒ Required for Order.

252 Make of Generator

254 Governor/Load Sharing Module

256 Voltage Regulation

258 Alarm Shutdown

260 Grounding System

262 PT Configuration

264 Breaker Trip Unit Type

266 Breaker Trip Unit Model

268 Breaker Size

270
 

MX-6000 LED Annunciator ☒ Yes

Spare Input No. 1

Spare Input No. 2

Spare Input No. 3

Spare Input No. 4

Event 1 Message

Event 2 Message

Event 3 Message

Event 4 Message

[Preview Quote](#)
[Save Quote](#)
[Submit Order](#)

136
 138
 140

FIGURE 7

280

[Search All My Quotes](#) 142    [Request New Quote](#) 144

### Product Configurator

User Name: John Doe  
 2/21/2001

Customer Name: Customer Name  
 Quote Number: xxx 123 1234

[Preview Quote](#) 136    [Save Quote](#) 138    [Submit Order](#) 140

124 Customer
126 Project Details
128 System
130 Engine Generator
132 Distribution Breaker
134 Pricing

### Distribution Breaker

☐ Required for Order

Trip Unit Type  282  
 Trip Unit Model  284

1	Select Frame Size	Select ATS	Select Load Block Priority
2	Select Frame Size	Select ATS	Select Load Block Priority
3	Select Frame Size	Select ATS	Select Load Block Priority
4	Select Frame Size	Select ATS	Select Load Block Priority
5	Select Frame Size	Select ATS	Select Load Block Priority
6	Select Frame Size	Select ATS	Select Load Block Priority
7	Select Frame Size	Select ATS	Select Load Block Priority
8	Select Frame Size	Select ATS	Select Load Block Priority
9	Select Frame Size	Select ATS	Select Load Block Priority
10	Select Frame Size	Select ATS	Select Load Block Priority
11	Select Frame Size	Select ATS	Select Load Block Priority
12	Select Frame Size	Select ATS	Select Load Block Priority

290

[Preview Quote](#) 136    [Save Quote](#) 138    [Submit Order](#) 140

FIGURE 8.